

Packing a N₂O Sensor Head for shipping



Place the Sensor Head in the cardboard protection sheet that came with the sensor. If this has been lost, another piece of cardboard may be used.



Close the cardboard with a piece of tape, a cable tie, a rubber band or similar. Make sure the Sensor Head cannot move.



Place one membrane insert with the membrane facing upwards. Place the Sensor Head on the membrane.



Place the second membrane insert with the membrane facing downwards. The Sensor Head must now be squeezed in between the two membranes.



Place the white cardboard insert on top of the membranes. This will press the upper membrane insert down so that the Sensor Head is firmly held in place between the two membranes.



Close the box and it is ready for shipping.

