




Find firmware version on N₂O Wastewater Controller



Enter the *Device menu* by pressing the date field on the main screen.
Press *Device info*



Press *General*



The firmware version is shown in *Setup quick info*